



HV320-PNET-V2
PROFINET Communication Card
User Manual

HNC Electric Limited

1. Overview

Thank you for using our HV320 V2 series inverter and PROFINET expansion card (hereinafter referred to as HV320-PNET-V2 card). HV320-PNET-V2 card is a Profinet fieldbus adapter card that complies with the international Profinet Ethernet standard. This card is installed on the HV320 V2 series inverter to improve communication efficiency and facilitate the inverter networking function, making the inverter a slave station of the fieldbus and accepting the control of the fieldbus master station.

This manual requires the corresponding HV320-PNET-V2 card software version to be 1.00 or above, and the matching GSDML file name is "HV320-PNET-V2.xml".

Please read this user guide carefully before using this product.



Figure 1-1 Appearance of the HV320-PNET-V2 card

2. Installation and Setup

2.1 Installing the HV320-PNET-V2 card

The HV320-PNET-V2 card is installed inside the HV320 V2 series inverter. Before installation, disconnect the power supply of the inverter and wait for about 10 minutes until the charging indicator on the inverter lights up. Then, insert the HV320-PNET-V2 card into the inverter and tighten the screws to avoid damage caused by the tension of the external signal cable on the inter-board signal socket.

Figure 2-1 shows the hardware layout of the HV320-PNET-V2 card. The 2* 8 P bent pin socket (CN1) is used to connect the inverter. The HV320-PNET-V2 card provides two network ports J 3 for communication with the master station and the slave station.

For hardware details, see Table 2-1




Figure 2-1 HV320-PNET-V2 card (hardware)

Table 2-1 Hardware description of the HV320-PNET-V2 card

Symbol	Hardware Name	Functional Description
CN1	Pin connector	For connecting to frequency converter
J3	Network Ports	Uses standard Ethernet RJ45 socket, no direction, use J3 to connect and communicate with PN card or PLC
LED2	PROFINET fault indicator (red)	The HV320-PNET-V2 card, see Table 2-2.
LED1	PROFINET communication indicator (green)	
LED3	Power indicator light (green)	
LED5	Inverter communication indicator light (green)	

Table 2-2 HV320-PNET-V2 card specification description

Indicator signal		Status description	Solution
LED 2	OFF state	Normal	N/A
	Always red	Communication failure	Please contact technical support.
LED 1	Always green	Normal PN	N/A
	OFF state	Communication with the drive is lost	P 0 - 28 to 1 and check if the AC drive supports the HV320-PNET-V2 card.
LED3	Always green	Normal	N/A
	OFF state	The communication board is not powered.	Check whether the J4 connector is connected properly and whether the inverter is powered on.
LED5	Always green	Normal	N/A
	OFF state	ESC internal fault	Please contact technical support.

2.3 PROFINET RJ45 interface

The HV320-PNET-V2 card uses standard Ethernet to connect to the PROFINET master station RJ45 socket. Its pin signal definition is the same as the standard Ethernet pin. They can be connected using a crossover cable or a straight-through cable.

Table 2-3 PROFINET communication interface description

Terminal Symbols	Terminal Name	Describe
J3	PROFINET interface 1	PROFINET network interface.
	PROFINET Interface 2	



- When facing the RJ45 interface. Both interfaces must be connected correctly.
- Cat5e shielded twisted pair (STP) network cable must be used to ensure stability.

3. Communication Configuration

3.1 Communication Configuration between HV320-PNET-V2 Card and HV320 V2 series inverter after installing the HV320-PNET-V2 card on the HV320 V2 series Inverter , complete the communication configuration to achieve communication between them.

■ Communication card settings for the inverter

Inverter [software version: L 8.00](#)

The following parameters must be set to enable the HV320-PNET-V2 card to communicate with the HV320 V2 series inverter and connect the HV320-PNET-V2 card to the PROFINET fieldbus network.

Function code	name	content	Settings	describe
P0-02	Run command source	0: Operation panel running command channel (LED off) 1: Terminal command channel (LED on) 2: Communication command channel (LED flashes)	2	Run command issued via communication
P0-03	Main frequency source X selection	0: Digital setting (preset frequency P0-08, UP/DOWN can be modified, no memory is stored after power failure) 1: Digital setting (preset frequency P0-08, UP/DOWN can be modified, power-off memory)	9	Given a target frequency By communication

		2: AI 1 3: AI2 4: AI 3 5: PULSE setting (DI 5) 6: Multi-segment instructions 7: Simple PLC 8: PID 9: Communication setting		
P0-28	Serial communication protocol	0: Modbus protocol 1: Communication card bridge protocol	1	Select special item communication card for communication

■ Communication control related function codes

Function code	name	Setting range	Decimal address
U3-16	Frequency setting	-Maximum frequency~Maximum frequency 0.01Hz	29456
U3-17	Control Commands	0001: Forward operation 0002: Reverse operation 0003: Forward jog 0004: Reverse jog	0005: Free stop 0006: Deceleration and stop 0007: Fault reset 29457
U3-18	DO control	BIT 0: DO 1 output control BIT 1: DO 2 output control BIT 2: RELAY 1 lose Out of control BIT 3: RELAY 2 lose Out of control BIT 4: FMR output control	BIT 5: VDO 1 BIT 6: VDO 2 BIT 7: VDO 3 BIT 8: VDO 4 BIT 9: VDO 5 29458
U3-19	AO 1 control	0~7 FFF means 0 %~ 100%	29459
U3-20	AO 2 control	0~7 FFF means 0 %~ 100%	29460
U3-21	FMP Control	0~7 FFF means 0 %~ 100%	29461
U3-22	reserve	reserve	
U3-23	Speed control	Signed data, 1 rpm	29463

When using the HV320-PNET-V2 card, the default mapping of PZD 1 is U3-17, and the default mapping of PZD 2 is U3-16 . If you find that the command or frequency cannot be written to the inverter normally, but PZD 3 to PZD 12 can be written, and P 0-02=2 and P 0-03=9, you can check whether PE 00 is U3-17 and PE 01 is U3-16 on the inverter . If not, please manually change them to the correct values.

■ **Communication monitoring related function codes**

Function code	Name	Unit	Decimal address
U0-00	Operating frequency (Hz)	0.01 Hz	28672
U0-01	Set frequency (Hz)	0.01 Hz	28673
U0-02	Bus voltage (V)	0.1V	28674
U0-03	Output voltage(V)	1V	28675
U0-04	Output current(A)	0.01A	28676
U0-05	Output power (kW)	0.1kW	28677
U0-06	Output torque(%)	0.10%	28678
U0-07	DI input status	1	28679
U0-08	DO output status	1	28680
U0-09	AI 1 voltage (V)	0.01V	28681
U0-10	AI 2 voltage (V)	0.01V	28682
U0-11	AI 3 voltage (V)	0.01V	28683
U0-12	Count value	1	28684
U0-13	Length value	1	28685
U0-14	Load speed display	100.00%	2868600.00%
U0-15	PID Setting	1	28687
U0-16	PID Feedback	1	28688
U0-17	PLC stage	1	28689
U0-18	PULSE input pulse frequency (Hz)	0.01 kHz	28690
U0-19	Feedback speed (Hz)	0.01 Hz	28691
U0-20	Remaining running time	0.1Min	28692
U0-21	AI 1 voltage before correction	0.001V	2869300.00%
U0-22	AI 2 voltage before correction	0.001V	28694
U0-23	AI 3 voltage before correction	0.001V	28695
U0-24	Line speed	1m/ Min	28696
U0-25	Current power-on time	1 Min	28697
U0-26	Current running time	0.1 Min	28698
U0-27	PULSE input pulse frequency	1Hz	28699
U0-28	Communication setting value	0.01%	28700
U0-29	Encoder feedback speed	0.01 Hz	28701
U0-30	Main frequency X display	0.01 Hz	28702
U0-31	Auxiliary frequency Y display	0.01 Hz	28703
U0-32	View the value of any memory address	1	28704
U0-33	Synchronous machine rotor position	0.1°	2870500.00%
U0-34	Motor temperature value	1°C	2870600.00%
U0-35	Target torque(%)	0.10%	28707
U0-36	Resolver position	1	28708
U0-37	Power factor perspective	0.1°	28709
U0-38	ABZ position	1	28710
U0-39	VF separation target voltage	1V	28711
U0-40	VF separation output voltage	1V	28712

U0-41	DI input status intuitive display	1	28713
U0-42	DO input status intuitive display	1	28714
U0-43	DI input status intuitive display 1	1	28715
U0-44	DI input status intuitive display 2	1	28716
U0-45	Fault Information	1	28717
U0-58	Z signal counter	1	28730
U0-59	Setting frequency(%)	0.01%	28731
U0-60	Operating frequency(%)	0.01%	28732
U0-61	Inverter status	1	28733
U0-62	Current fault code	1	28734
U0-63	Operating frequency after droop control	0.01 Hz	38375
U0-64	Current Back EMF	0.1V	28736
U0-65	reserve	-	-
U0-66	Expansion card model	100: CANopen 200: Profibus - DP 300: CANlink 400: Profinet 500: EtherCAT	28738
U0-67	Expansion card version number	0.01	28739
U0-68	Inverter status	1	28740
U0-69	Operating frequency (Hz)	0.01 Hz	28741
U0-70	Motor speed	1 rpm	28742
U0-71	Output Current	0.1A	28743

When using the HV320-PNET-V2 card, the default mapping of PZD 1 is U0-68, and the default mapping of PZD2 is U0-69 . If you find that the status or operating frequency cannot be read normally, but PZD3~ PZD12 can be read, you can check whether PE-20 is U0-68 and PE-21 is U0-69 on the inverter . If not, please manually change it to the correct value.

3.2 Profinet communication

3.2.1 Profinet topology

The topologies supported by Profinet include bus, star, tree, etc. Through the rational use of switches, a variety of networking can be achieved.

The following diagram shows the bus topology




Figure 3-1 Bus connection topology




Figure 3-2 Star connection topology




Figure 3-3 Tree connection topology

3.3.3 Data transmission format

PROFINET Data Format

According to the ProfiDrive (variable speed transmission) protocol , the usage types are divided into five types : PPO type : PPO1, PPO2, PPO3, PPO4, PPO5

The functions that each data format can accomplish are as follows:

Table 3-2: PPO type description

Data Types	Supported Features
PPO1	<ul style="list-style-type: none"> ● Single function parameter operation ● Inverter command, frequency setting ● Inverter status, operating frequency reading
PPO2	<ul style="list-style-type: none"> ● Single function parameter operation ● Inverter command, frequency setting ● Inverter status, operating frequency reading ● 4 function parameters are written periodically ● 4 function parameters are read periodically
PPO3	<ul style="list-style-type: none"> ● Inverter command, frequency setting ● Inverter status, operating frequency reading
PPO4	<ul style="list-style-type: none"> ● Inverter command, frequency setting ● Inverter status, operating frequency reading ● 4 function parameters are written periodically ● 4 function parameters are read periodically
PPO5	<ul style="list-style-type: none"> ● Single function parameter operation ● Inverter command, frequency setting ● Inverter status, operating frequency reading ● 10 function parameters are written periodically ● 10 function parameters are read periodically

PPO Type Description

The data block contained in the PPO type data format is divided into two areas, namely the PK W area (parameter area) and the PZ D area (process data area). The type data format is shown in the figure below




Figure 3-4: PPO type data format

PKW Data Description

PK W data mainly realizes the master station's read and write operations on a single parameter of the inverter. The communication address of the inverter parameter is directly given by the communication data. The functions realized are as follows

- a) Reading inverter function parameters
- b) Change of inverter function parameters

Data Format

PKW data contains three groups of array areas, namely PKE , IND, and PWE, among which the PKE data byte length is 2 bytes, IND is 2 bytes, and PWE, PWE is 4 bytes.

The data format is shown in the following table:

TABLE 3-3: PKW DATA FORMAT

The master sends data PKW							
Operation Command	Parameter address		Reserve			Write operation: parameter value Read operation: empty	
PKE	PKE	IND	IND	PWE	PWE	PWE	PWE
Communication card response data PKW							
Operation Command	Parameter address		Reserve			Success: Return value Failed: Error message	
PKE	PKE	IND	IND	PWE	PWE	PWE	PWE

Table 3-4: PKW data description

Master sends data PKW description		Inverter response data PKW description
PKE	High 4 bits: command code 0: No request 1: Read parameter data 2: Change parameter data (The above command codes are decimal numbers according to) Lower 4 bits: reserved Lower 8 bits: parameter address high bits	High 4 bits: Response code 0 : No request 1 : Parameters are correct. 7 : Unable to execute Lower 8 bits: parameter address high bits
IND	High 8 bits: parameter address low bits Lower 8 bits: reserved	High 8 bits: parameter address low bits Lower 8 bits: reserved
PWE	High 16 bits: reserved Lower 16 bits: not used for read requests; indicates parameter value for write requests	When the request is successful: parameter value When a request fails: Error code (same as standard MODBUS Consistent) 1 : Illegal command 2 : Illegal address 3 : Illegal data 4 : Other errors

Application Examples

The master station reads the inverter function parameter P 0-08 sending data PK W area and the inverter response data PKW area as shown in the figure below:




Figure 3-5: Example of the master station reading inverter parameters and sending PKW data

PZD area data description

The PZD area enables the master station to modify and read the inverter data in real time and exchange data periodically.

The frequency converter is directly configured. It mainly includes the following contents:

- a) Inverter control command and target frequency are given in real time
- b) Real-time reading of the inverter's current status and operating frequency
- c) Real-time interaction of function parameters and monitoring parameter data between the inverter and the PROFINET master station

Note: " GSDML-V2.31-EM-PNCard-20230520.xml " or later versions

The default mapping of PZD1 written is U3 - 17, and the default mapping of PZD2 is U3 - 16 .

The default mapping of PZD1 read is U 0 - 68 , and the default mapping of PZD2 is U 0-69 .

PZD process data mainly completes the periodic data interaction between the master station and the inverter. The interaction data is shown in Table 8 below :

Table 3-5 Interaction data


Master sends data PZD area			Inverter response data PZD area		
PZD1	PZD2	PZD3~PZD12	PZD1	PZD2	PZD3~PZD12
Control Word (U3-17)	Frequency setting (U3-16)	Real-time change of inverter function parameters	Status word (U0-68)	Operating frequency (U0-69)	Real-time reading of inverter function parameters

Table 3-6

Master sends data PZD description		Inverter response data PZD area	
PZD1	<p>Inverter command word (the command source needs to be set to communication, that is, P0-02=2)</p> <p>0001: Forward operation</p> <p>0002: Reverse operation</p> <p>0003: Forward jog</p> <p>0004: Reverse jog</p> <p>0005: Free stop</p> <p>0006: Deceleration and stop</p> <p>0007: Fault reset</p> <p>0008: Fault reset (fault reset is only possible in communication control mode)</p>	PZD1	<p>Inverter operating status information interest</p> <p>0001: Forward operation</p> <p>0002: Reverse operation</p> <p>0003: Shutdown</p>
PZD2	<p>The inverter target frequency (frequency source is set to "communication") is in the range from the negative frequency upper limit (negative value) to the positive frequency upper limit (including the decimal point, for example, 2000 corresponds to 20.00 Hz on the AC drive). When the given target frequency exceeds this range, the AC drive runs at the frequency upper limit.</p> <p>For example, if the Frequency High Limit setting is 50.00 Hz and the Comm Setting is 6000, the AC drive will run forward at 50.00 Hz. If the Frequency High Limit setting is 50.00 Hz and the Comm Setting is -6000, the AC drive will run reverse at 50.00 Hz.</p>	PZD2	<p>Inverter operating frequency (unit: 0.01Hz)</p> <p>Returns the actual operating frequency of the current inverter. The returned data value is a 16-bit signed data.</p>
PZD3~ PZD12	<p>Change function parameter values in real time , do not write to EEPROM</p>	PZD3~ PZD12	<p>Function parameters real-time reading</p>

4. Configure the slave with S7-1200 in TIA Portal


- 1) Open TIA Portal V13, create a new project, and add an S7-1200 master station according to actual conditions.




Adding the Siemens PLC , switch to the "Project View"


- 2) Install GSD file (if GSD is already installed, you can skip this step)

GSD file that has not been installed will be displayed as "Not installed yet". Check it and select "Install" and wait for the installation to complete (it is recommended that the installation path does not contain Chinese, otherwise an error may be reported) .







When the "Successfully installed" interface appears, click Close. After the GSD installation is complete, PORTAL will automatically close the configuration interface. After the installation is complete, you can find HV320-PNET-CARD in the hardware device tree. The corresponding equipment is as shown below




3) Configure the network

HV320-PNET-CARD under the "Hardware Catalog" to the "Network View" of "Device & Network", click "Unassigned" on the slave station, and connect to the Profinet corresponding to the PLC . On the network,




(2) Double-click HV320-PNET-CARD icon to enter the configuration module,

Select the appropriate PPO type in the "Hardware Catalog" and pay attention to the addresses assigned to each segment. As shown in the figure below, the marked part corresponds to the address of the PKW . If the selected PPO does not have a PKW , this column will be blank.



4) Setting PZD Mapping

Switch back to "Network View" and click "Device Specific Parameters" to set the mapping of PZD3 —> PZD12 . Note that the PZD mapping of the PLC read and write slaves is set separately and does not interfere with each other. For specific setting methods, please refer to the introduction of this part of STEP7 .




PZDx (master->slave) indicates the address that the master writes to the slave, and PZDx (slave->master) indicates the address that the master reads from the slave. The configurable PZD range is PZD3~PZD12 (depending on the selected message type). The display format is decimal. For example, if you want to set PZD3 (master->slaver) to P 0-12, you need to enter 61452 in the value of this row.

The default value of all PZDs of the HV320 V2 series inverter is P 0-00 (corresponding to 61440 in decimal). PZDs that are not used can be left unchanged and retain the default value. Each slave needs to set the PZD mapping relationship according to the requirements (if the mapping relationship of each slave is the same, you can select a pre-set slave, press CTRL+C, then select the Profinet bus in the configuration and press CTRL+V to directly modify the device name and IP address).


Switch back to "Network View". If you need to add more sites, repeat the above steps. If the configuration is the same, you can directly select the slave site and copy it, and then modify the IP address and device name (Note: the device name must be consistent).

5) Configure the module communication address




6) Set the device name of the inverter hardware


Click the inverter and right-click to display the drop-down menu. Then click the "Assign device name" option to pop up a dialog box..



Select the corresponding network card and click "Update list"



Select the inverter corresponding to the MAC code, and then click "Assign name" to complete the inverter name setting.



Edition: V2.0

Thanks for choosing HNC product.

Any technique support, please feel free to contact our support team

Tel: 86(20)84898493 Fax: 86(20)61082610

URL: www.hncelectric.com

Email: support@hncelectric.com

